



Double/King



Super King



Important Information

- We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
- Carefully check that you have all the parts before beginning assembly.
- Keep fittings out of children's reach and keep children well away from construction area.



An instructional video of the operation of the Ottoman Lift Up System is available via YouTube using the following address: https://youtu.be/hyq4zm7h_yU

	Press once and TV will rise to it's upper working position. Power to the TV will be connected automatically
	Press once and TV Lift will stop.
	Press once and TV will go down - as soon as the lower resting position is reached power to the TV is switched off to prevent it overheating.
	Torch
	Code Matching
	Code Matching (pairing): occasionally pairing is lost perhaps due to atmospheric conditions, To re-pair - press and hold the code matching button whilst connecting the power by plugging the mains cable into the control box of the TV lift on the base of the footboard. Continue to press the button for another 5 seconds then press the up or down button to successfully match the code. Regularly check the batteries and if necessary re-place them - x3 pcs AAA size.

GENERAL INFORMATION

It is very important not to place any vessel containing liquids, e.g. drinks or vase of flowers on top of the TV footboard that may accidentally spill and enter the TV compartment as this could cause damage to the TV and/or the TV lifting equipment. If this happens turn off the power and contact your retailer.

Do not expose the bed to an undue level of heat - keep away from radiators.

Never allow anyone to sit on the foot end of the bed - keep children well away from moving parts.

To keep your bed clean, we recommend that it be wiped over with a slightly dampened cloth, or if fabric, use a light vacuum cleaner; disconnect power before cleaning.

Supplied with the bed is a remote control to operate the TV Lift and there will be one to operate the television itself. Both these remotes will be supplied with batteries - there are no batteries in the rest of the equipment.

When it is time to change the batteries there are strict controls for disposal of the old ones - your local council can advise on how to safely dispose of them. Never burn batteries on an open fire as they could explode.

Ottoman Beds - Important Safety Features

Our aim is always to give you the best experience and to ensure every effort has been made to guarantee your comfort and safety. Please take time to look at these instructions as they will help remind you how to operate your ottoman bed safely.


Here's a few things you need to remember;

- ✓ **Pistons are already assembled in their correct orientation – this improves piston performance and durability.**
- ✓ **“Break in ” the piston seals on first use by raising & lowering the platform at least five times.**
- ✓ **Recommended mattress weights - do not exceed the maximum relevant weight specified on the Assembly Instruction.**
- ✓ **Ottoman support bar – always engage the support bar when accessing the ottoman storage area.**

Read all the instructions before using your Ottoman bed-frame and save the instruction booklet for future reference.



Ottoman Support Bar (O.S.B.)

For optimal safety during operation, always ensure the O.S.B. is engaged when accessing the ottoman storage area.



1. Always raise the ottoman slat-frame to it's highest position before using the storage area.
Locate the end of the O.S.B and insert into the fixed retaining bracket on the bed frame.
2. When you are ready to lower the ottoman platform, return the O.S.B to its original parking position.
3. Always ensure that the O.S.B is in position when the ottoman is open, this prevents injury, or damage to the product.

Location of the O.S.B



WARNING! Risk of Entrapment

- The pistons on the ottoman bed frame can support a maximum load (evenly spread) as indicated in the Minimum and Maximum load table shown in the main Assembly Instruction.
- Overloading the sleeping platform may contribute to damage to the product resulting in potential serious injury.
- Do not sit on the mattress whilst the platform is in motion or is in the raised position.
- Users should only get in and out of bed when platform is in the flat (horizontal) position.


Warning

- You must ensure that the mattress is on the bed frame before operating the lift mechanism, failure to do so could result in injury.
- Keep hands clear of the mechanism when opening or closing the ottoman.
- Beware of entrapment – Never reach in through the mechanism to access the storage area.
- Always be sure that the ottoman is FULLY opened before accessing the storage area.
- Do not exceed the maximum weight as specified in the table below:

Bed	BedSize	Min Weight (kg)	Max Weight (kg)
FALLON Ottoman TV Bed	Double	20	50
	King	20	50
	Super King	20	50



- Use caution when operating, always use the handle when lifting.
- Note: This bed uses a pressurised mechanism.
- To be operated by adults only
- Please ensure that children and pets are kept away from the bed when operating the lift mechanism.
- Keep children and pets away from the storage area.
- Do not overload the internal storage base.
- Do not stand inside the internal storage area of the bed.
- Before removing the mattress secure the frame to ensure it does not open unexpectedly.
- Do not attempt to lay on the mattress when the ottoman is in the raised position.











Fully Open Ottoman: Ensure the ottoman is fully open before accessing the storage area.
Avoid Hinge Area: Do not reach into the storage area through the hinge mechanism.
Keep Children and Pets Away: Ensure children and pets stay away from the storage area. Do not stand inside the internal storage area of the bed.
Maintenance: Regularly inspect your bed to ensure it is functioning correctly.


Adult Operation Only: Not recommend for use by under 12 years old. Please note ease of operation is dependent on height and strength of user.
Avoid Entrapment: Always lift the bed with the mattress in place, using the handle to lift and lower the base, keeping clear of the mechanism.




Note: Be very careful what you store under the bed - the top of an item, like a box or a suitcase, must not touch the slats or they may be damaged. Maximum storage height is 280mm.






Headboard Carton 1 - The Components are Packed in the Storage Compartment at the Back

(1) Headboard x1 	(7) Gas-lift Mechanism x1 -Right 	(8) Gas-lift Mechanism x1 -Left 	(9) Gas-lift Piston x2 
(12) Fabric Base Cover x1 	(13) 'L' Shape Bracket x4 	(14) Spacer Rail For Gas Lift Mechanism x2 	(15) Bentwood Slat (Double x 28) (King x30) (Super King x45) 
(20) Wing-Right x1 	(21) Wing-Left x1 	(22) Corner Hook-Left x1 	(23) Corner Hook--Right x1 
(24) Flat Hook Bracket x2 	A Double x28 King/Super king x30  End Cap	B Double x14 King x15 Super King x30  Centre Cap	

O.S.B & INSTALLATION KIT





(25) Fixed Retaining Bracket x1 	(26) Parking Bracket- x1 	(27) Ottoman Support Bar x1 	K x5  Bolts M8x25mm	H x5  Spring Washer for M8 Bolts	I x5  Flat Washer for M8 Bolts
--	---	--	---	---	---

Footboard Carton 2 - The Components are Packed Inside the Footboard

(2) Footboard x1 	CABLES & ACCESSORIES FOR TV INSTALLATION			
	(16) Mains Power Lead x1 	(17) Remote Control x1 	(18) Cable Clips x3 	(19) Cable Ties x3 
(4) Fabric Handle x1 	TV INSTALLATION KIT - HARDWARE FOR FITTING THE TV			
	a  M8 x25mm x2  M6 x12mm x2  M4 x12mm x2		b  Allen Key (4mm)  Allen Key (2.5mm)	


Footboard Carton 2 - The Hardware is Packed Inside the Footboard

HARDWARE FOR ASSEMBLING THE BED



(11) Mattress Stopper x2 	C x36  Bolt M8x25mm	D x4  Bolt M8x35mm	E x4  Bolt M8x50mm	F x6  Threaded Stud(M8x60)
G x6  Nut For M8 Bolts	H x6  Spring Washer For M8 Bolts	I x6  Flat Washer For M8 Bolts	L x1  Allen Key M8 Bolts	M  Spanner For M8 Nuts

Hardware Packed in Carton 2


HARDWARE FOR ASSEMBLING THE METAL SLAT FRAME

E Double/King x12 Super King x14  Bolt M8x50mm	H Double/King x12 Super King x14  Spring Washer M8	I Double/King x12 Super King x14  Flat Washer M8	J Double/King x16 Super King x18  Flanged Lock-Nut M8	
--	--	--	---	--

Side Rail Carton 3 - The Components are Packed inside with the Side Rail


(3) Side Rail x2 	(5) Side Rail Cross Bar x1 	(6) Long Slat Frame Tube Double/King x3 Super King x4 	(10) Slat Frame End Tube x2 
---	---	---	--

Step 1




Unzip the cover on the back of the headboard and take out all components, these are all needed to assemble the bed.

Step 2





Step 3

G  x6 H  x6 I  x6 M  x1




Step 4

C  x18 L  x1




Step 5




Make certain the bed is squared up as shown in the diagram then tighten all bed assembly bolts 100%.

Step 6





Step 7

C  x12 L  x1



Step 8a

D  x4 E  x4 L  x1







Step 8b


D  x4

E  x4


L  x1





Step 9



Connect the mains power lead (16) to your wall socket – for safety this must be an earthed power supply.



Step 10



Press the "UP" button to raise the TV lift.



Step 11


Note: For illustration purposes only, TV connections may vary.

TIP:
BEFORE FITTING THE TV, PUSH CABLES THROUGH EACH DUCT FROM THE TOP. CHOOSE THE BEST SIDE TO USE DEPENDING ON WHERE THE CONNECTION PORTS ARE ON BACK OF YOUR TV. NEVER CROSS CABLES FROM ONE SIDE TO THE OTHER.

Leads for HDMI or Aerial
(not supplied)

TV Power Lead supplied
with your own TV
(not supplied)

If required, please
purchase HDMI leads
about 3mt long and length
of aerial lead to suit the
position of your wall socket.














Step 12

TV Installation - Normal Vesa Fixing

IF SCREWS ARE SUPPLIED WITH TV, PLEASE USE THOSE IN PREFERENCE

Choose a suitable set of hardware





- a) Bolt sets M8 x 25mm  Counter-sunk screw sets (M6x12mm)  Counter-sunk screw sets (M4x12mm) 
- b) Allen key (2.5mm)  Allen key (4mm) 





Step 13

Note: For illustration purposes only, TV connections may vary.

TV power lead supplied
with your own TV





PLUG IN - KEEP ALL CABLES TIGHT
- USE CLIPS & TIES PROVIDED.




Keep wires tight - peel off
cover from cable clips &
adhere to back of TV.

Step 14





Press the "DOWN" button to lower the TV lift.



Connect your aerial lead if required.
(not supplied)

Step 15a

**For Double
and King Size**








Fully Open Ottoman: Ensure the ottoman is fully open before accessing the storage area.
Avoid Hinge Area: Do not reach into the storage area through the hinge mechanism.
Keep Children and Pets Away: Ensure children and pets stay away from the storage area. Do not stand inside the internal storage area of the bed.
Maintenance: Regularly inspect your bed to ensure it is functioning correctly.

Adult Operation Only: Not recommended for use by under 12 years old. Please note ease of operation is dependent on height and strength of user.
Avoid Entrapment: Always lift the bed with the mattress in place, using the handle to lift and lower the base, keeping clear of the mechanism.





Step 15b

**For Double
and King Size**



Step 16a

For Super King Size








Fully Open Ottoman: Ensure the ottoman is fully open before accessing the storage area.
Avoid Hinge Area: Do not reach into the storage area through the hinge mechanism.
Keep Children and Pets Away: Ensure children and pets stay away from the storage area. Do not stand inside the internal storage area of the bed.
Maintenance: Regularly inspect your bed to ensure it is functioning correctly.

Adult Operation Only: Not recommended for use by under 12 years old. Please note ease of operation is dependent on height and strength of user.
Avoid Entrapment: Always lift the bed with the mattress in place, using the handle to lift and lower the base, keeping clear of the mechanism.







Step 16b

For Super King Size







Step 17

J  x2 M  x1




Step 18

E  x6 J  x6 H  x6 I  x6
L  x1 M  x1




Step 19


J  x2 M  x1




Step 20

Unpack the contents of the Ottoman Support Bar (O.S.B).


K  x5 H  x 5 I  x5 L  x1



Step 21 **Setting the inner stem of the support bar (27), adjust the inner stem to the correct length.**



Set the inner stem to the correct length so the end just touches the retaining bracket -it needs to touch to hold it in position.



Technical Specifications

Max TV Size: 980 x 570 x 80 (WHDmm)

Overall Dimensions (LWH mm)

Double: 2230 x 1450 x 1185

King: 2330 x 1600 x 1185

Super King: 2330 x 1900 x 1185

Storage Dimensions (LWH mm)

Double: 1950 x 1380 x 280

King: 2050 x 1530 x 280

Super King: 2050 x 1830 x 280

Ottoman Piston Strength

Double/King: 800N

Super King: 900N

Distance between slats (mm)

Double: 70

King: 68


Super King: 68

Slat Dimension (mm)

Double: 665 x 53 x 9.5

King: 740 x 53 x 9.5

Super King: 590 x 53 x 9.5



IMPORTANT POWER INFORMATION

Before fixing the mattress baseboards to the bed, please follow the instructions below:

Plug in the main power supply lead supplied with your bed; this is packed inside the TV footboard.

It is essential that this power lead is connected to an earthed socket be it a wall socket or extension lead - otherwise there is risk of damage or even electric-shock.

The wall socket providing the power must be accessible at all times in case you need to switch off the electric supply.

Power cable supplied with this bed or other approved mains powered extension leads used to power your equipment must not be placed where they can be walked on - this is dangerous and could lead to accidents.

Power outlets, extension leads or adapters must not be overloaded beyond their limit - this can result in fire or electric shock.

During an electrical or lightening storm - disconnect the power completely as a precaution.

Always un-plug the power when going on holiday or when the bed is not used for an extended period.

If you have young children in the home always disconnect the power at the wall socket for extra safety.

Do not interfere with or modify any cables already fitted and do not add any media cables unless they are routed through the ducts as shown. All leads must be tightly connected to back of TV, never hanging loose where they can get trapped.

Never touch moving parts or any part of the equipment - if something needs to be checked, disconnect the power first.

Do not insert anything into the footboard as this could seriously damage the TV and/or the TV lifting equipment and could, if done carelessly, cause serious damage or injury.

If the equipment doesn't operate normally or if there is any unusual noises, disconnect the power and contact your retailer for advice.

TELEVISION INFORMATION

Please follow the assembly steps for initial operation of the TV Lift, your TV and any media cables required.

Push the television power plug (supplied with your own TV), into it's own special socket which is on the face of the footboard clearly shown in the instructions. For safety and to prevent overheating, this socket is only to be used for the television as it does not have a constant power supply.

Raise the TV Lift by pressing the UP button of the remote control.

If required you can connect media cables the television ports.

Please use the cable clips & cable ties to make certain there are no loose wires to snag or get trapped.

The television can now be operated following the TV User Guide.

When finished viewing, lower the television back into the footboard by pressing the DOWN button of the remote control.

For safety and to stop any overheating, power to the television is switched off when lift reaches the bottom rest position.

When the UP button is pressed - the TV Lifting Column rises and power is turned back on automatically.

TROUBLE SHOOTING

- If your equipment does not operate please check all the electrical connections to the wall socket and check that electricity is reaching the main power input plug bringing power to the footboard.
- Make sure that the TV is switched on - but note that the television will only work when it is in the up position.
- Check that the remote control has not lost its connection with the TV Lift - please see pairing instructions on Page (1).

IMPORTANT: Care should be taken when connecting electrical items. If you are in any doubt about the connections please consult an approved electrician. If you still have a problem please contact your retailer for advice.